Attach the battery pack on the belt buckle using the clips. Adjust the retractable cord so that there is a comfortable level of pressure. Do not pull on the cords. Pulling on the cords could damage the wire contacts which could cause the battery pack to overheat to temperatures surpassing 100°C. If the heater pad will be used by children, they must first be tested by a parent or adult to confirm that the battery pack is not generating heat and that installation is done according to this manual.
The actual temperature of the element is dependent upon ambient temperature, shoe insulation and battery quality.
For permanent installation remove the release liner on the bottom of the heater pad and adhere the black foam adhesive to the sole of the shoe. For temporary use, do not remove the release liner.

Ensure that the cords are situated so that they will not be entangled in a ski lift,or caught in skis and will not inhibit normal movement and activities.

Operation:
Install 2 AA size batteries into each battery case - total 4 AA batteries (batteries not included with Foot Warmer).
Rechargeable batteries are recommended for repeat use. Turn the battery case switch from the OFF to the ON position to start heating.
After use, remove the foot heater taking care not to pull on the wires.
Dispose of the batteries in accordance with your local battery disposal laws.